




Spare Parts List




DZ*Trend*


2002-01-01



Pos. No.	Order no.	Notes	Pos. No.	Order no.	Notes
1	4310-04		43	4442-19	
2	9962-04	M8x20	44	3270-06	
3	9930-32	D8/17	45	4442-09	
5	9969-31	M8	46	2871-01	
6	9990-55		47	4310-07	
7	4416-01		48	3210-05	
8	9934-34		49	9968-44	D10/21
9	4374-03		50	9990-21	
10	9969-15	M6	51	9963-01	M10x25
11	9930-02	D6/12	52	9933-25	Ø2x10
12	4474-02		53	4611-01	
13	9964-02	M6x16	54	4512-12	
14	4471-11	Left	55	4612-01	
15	4471-12	Right	56	4960-81	
16	4612-01		57	9990-43	
18	9909-27	M8x16			
19	4412-05	Left			
20	4412-08	Left			
21	4412-09	Right			
22	4412-06	Right			
23	4412-20				
24	4412-21				
25	4441-05				
26	4441-06				
27	4012-11				
28	9937-30	U44			
29	9962-03	M8X16			
30	4440-01				
31	4320-01	DZ			
32	4473-01				
33	4473-02				
34	9968-16	M12			
35	9930-35	D12/24			
36	9985-27	710 mm			
37	4470-01				
38	9964-45				
39	4442-25				
40	9969-45	M10			
41	9934-26	Ø4,5x20x15			



Pos. No.	Order no.	Notes	Pos. No.	Order no.	Notes
1	4650-02	540/750 rpm	42	4652-09	6206-2RS
2	4160-01	Right	43	9950-03	
3	4160-02	Left	44	4652-01	
4	4056-10		45	3260-09	
5	4056-03		46	9990-90	
6	4058-05	Right	47	3263-00	M12x65
7	4058-06	Left	48	3260-07	
8	4161-02	Left	49	9965-02	
9	4161-01	Right	50	9934-03	
10	4158-05		51	9969-60	
11	9913-20	Ø20xØ30x5 M8x20 D8/17 M8	52	4653-10	14x20x10 14x22x4
12	4560-01		53	9934-02	
13	9929-35		54	4653-02	
14	9930-32		55	9990-99	
15	9969-31		56	9936-29	
16	4550-05	Left	57	9934-31	PA.
17	4550-06	Right	58	9930-51	
18	9933-02	Ø8x40	59	9934-01	
19	9933-11	Ø5x40	60	4653-20	
20	4051-05		61	9930-07	
21	9936-37	35x62x12	62	9961-04	M6x16
22	9950-02	6305-2RS	63	9962-03	M8x16
23	4155-04	Right thread	64	9965-01	M12x35
24	9933-12	Ø8x45	65	9930-35	D12/24
25	9933-17	Ø5x45	66	9969-62	M12
26	3265-02	15 teeth	67	4651-12	E1 T 2 Left/2 Right U14
27	3262-05		68	9936-28	
28	3260-04		69	9937-13	
29	9913-43	M10x25			
30	3260-05				
31	4062-05	Left thread			
32	4454-05	I60			
33	9937-40				
34	4457-02				
35	4456-02				
37	9931-56	8x7x25			
38	4652-03	17/24 teeth			
39	4652-08				
40	4652-10				
41	4660-00				



Pos. No.	Order no.	Notes	Pos. No.	Order no.	Notes
1	4381-06				
2	2810-18	D8/25			
3	9962-03	M8x16			
4	3961-30				
5	9969-31	M8			
6	9930-32	D8717			
7	9962-04	M8x20			
8	4381-07				
9	9961-04	M6x16			
10	9930-02	D6/12			
11	9969-15	M6			
12	9930-35	D12/24			
13	9969-60	M12			
14	4581-36				
15	9934-31				
16	4381-03	185/220 mm			
17	9934-32				
18	4581-29				
19	9990-52				
20	4581-10				
21	9934-14				
22	9990-60	D24			
23	9987-04				
24	9990-61	D40			
25	4581-15				
26	9983-29				
27	9936-79				
28	9982-06				
29	9990-84				
30	9936-80				
31	9983-09				
32	9990-85				
33	9990-19				
34	4581-25				
35	4581-28				
36	4581-37				

2013-08-09



Spare parts list *DZ_{Trend}* from machine no. 2075

**Reservedelsliste
Ersatzteilliste
Reservdelsslista
Lista de piezas de recambio
Liste de pièce de rechange
Onderdelenslijst
Varaosaluettelo**

BOGBALLE A/S

Bogballe · DK-7171 Uldum

Tel.: +45 7589 3266

Fax: +45 7589 3766

E-mail: bogballe@bogballe.com

www.bogballe.com